



**FUEL MOTO MICRO EFI TUNER
INSTALLATION INSTRUCTIONS
2007-2013
HARLEY-DAVIDSON
SPORTSTER 883 & 1200 MODELS**



PARTS LIST

1	Micro Tuner Module	1	Alcohol swab
1	USB Cable	1	Posi-tap
1	Installation Guide	2	Velcro strips

PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION

Note: Fuel Moto USA and Fuel Moto Micro EFI Tuner fuel management systems are not legal for use or installation on motor vehicles operated on public highways in the State of California or other States where similar emission and decibel regulation laws may apply. The user shall determine suitability of the product for his or her use. The user shall assume all risk and liability in violation of regulations and any incurred financial obligations due to vehicle inspections or emissions tests.

Fuel Moto USA


2215 Kelbe Dr., Little Chute, WI 54140

Phone: 920-423-3309


www.fuelmotousa.com



- 1 Remove the stock seat.
- 2 Route the Micro EFI Tuner from the seat area, under the frame tube, and continue towards the front of the bike (Fig. A).



- 3 Unplug the stock wiring harness from both of the fuel injectors (Fig. B).



- 4 Plug the Micro EFI Tuner wiring harness in-line of the stock wiring harness and the fuel injectors (Fig. C).

There are 2 pairs of fuel injector connectors on the Micro EFI Tuner wiring harness.

Plug the connector pair with ORANGE colored wires in-line of the FRONT fuel injector and stock wiring harness.

Plug the connector pair with YELLOW colored wires in-line of the REAR fuel injector and stock wiring harness.

FIG.D



5 Unplug the stock Throttle Position Sensor connector from the bike's TPS.

This connector is on the rear of the throttle body, behind the airbox.

6 Use the supplied Posi-tap to attach the GREY wire of the Micro EFI Tuner harness the GREY/PURPLE wire of the stock TPS (Fig. D).

7 Plug the stock TPS connector back onto the TPS.





FIG.E



8 Remove the bolt that holds the battery bracket in place. Pull the battery away from the bike far enough that you can access the ground wire.

9 Secure the ground wire of the Micro EFI Tuner harness (BLACK wire w/ ring eyelet at the end) to the negative terminal of the bike's battery (Fig. E).

10 Reinstall the battery.

FIG.F



11 Install the Micro EFI Tuner module under the seat (Fig. F).

12 Reinstall the seat.



- STATUS Light
- MAP Select
- LOW RPM Dial
- MID RPM Dial
- HIGH RPM Dial
- USB Port

Selecting the Map Position

The Fuel Moto Micro EFI Tuner comes loaded with up to ten maps. Using a #1 Phillips screwdriver, turn the map select dial to toggle between the loaded maps. Refer to the map position table below for the maps included in your Micro EFI Tuner Module.

Using the RPM Range Dials

The Low, Mid, and High RPM Dials refer to the RPM range, in thirds, of your vehicle. Each dial allows +/- 10% fuel adjustment on top of what fuel changes are done in the map. With the dial facing straight up, there is no additional fuel change

For example, if your vehicle revs to 6000 RPM:

- The low RPM dial will adjust 0-2000 RPM
- The mid RPM dial will adjust 2001-4000 RPM
- The high RPM dial will adjust 4001-6000 RPM

Using Fuel Moto Micro EFI Tuner Control Center

Take your tuning to the next level with the Fuel Moto Micro EFI Tuner Control Center software.

- 1 Go to <https://www.fuelmotousa.com/p-28236-fuel-moto-micro-efi-tuner.html> to download the software
- 2 Click Install Software and follow the on-screen instructions to install the Micro Tuner software. The Micro EFI Tuner software and maps will be stored in C:\Program Files\Fuel Moto Micro EFI Tuner Control Center.

Loading Additional Maps

- 1 Connect the USB cable from the computer to the Fuel Moto Micro EFI Tuner Module. Verify the cable is fully seated in the Fuel Moto Micro EFI Tuner Module.
- 2 Run the Fuel Moto Micro EFI Tuner Control Center software by double-clicking the program icon installed on your desktop or on your start menu.
- 3 Click Open Map File and select a map file.
- 4 Click Send Map. You can send the map to any of the ten map positions .

Altering Maps Using Software

The values in the map represent a percentage of fuel change over stock. A value of 10 in the map indicates at that throttle position and RPM range the vehicle will be 10% richer than stock. If the value is -10, then it would be 10% leaner than stock. You have the ability to fine tune your fuel curve by altering these values . The Control Center software allows a value of +250 to -100 in each cell.